


Quickstart Guide

Endian Mercury



Ethernet Activity LED

Status LED

Power LED

Hard Disk Activity LED

endian

What You Have and What You Need

With your Endian Appliance box you receive:

- ✓ Endian Appliance
- ✓ Power Supply Unit
- ✓ 1 Ethernet cable
- ✓ 1 console cable

To install your Endian appliance and protect your network you need:

- ✓ Power connection
- ✓ Network connection

Installation



A DHCP server is running on Ethernet port 1 of your appliance. If you already have a DHCP server in your local network make sure to connect your computer directly to Ethernet port 1, go through the installation procedure and connect the appliance to your local network only after having disabled the DHCP server.

1. Place your Endian appliance on a steady surface.
2. Connect your computer to Ethernet port 1 of the Endian appliance.
3. Connect the last Ethernet port of your Endian appliance to the uplink. The appliance will automatically try to connect to the Internet via DHCP once turned on.
4. If you are using a mobile broadband connection, plug in your USB key instead.
5. Connect the AC power cord to the AC power socket and push the power button.
The Endian appliance turns ON.

Web Interface

1. After booting the appliance your PC will automatically get an IP address from the Endian appliance.



If your computer is not set up to configure its IP address through DHCP you will need to configure your PC's Ethernet interface manually. In that case configure your interface with an IP address belonging to the 192.168.0.0/24 subnet that is different from 192.168.0.15 (which is the IP address of the Endian appliance).

2. Open your Internet browser (e.g. Mozilla Firefox) and go to address 192.168.0.15

The system will redirect you to <https://192.168.0.15:10443/> and the Configuration Wizard will start, and you need to select your language and accept the License.

Choose Your Configuration Mode

You have 3 choices:

1. **Plug & Connect:** if you have an Endian Switchboard this is the easiest way to connect and activate your Endian appliance



You (or someone from your company) must initially configure your device on the Switchboard in order to utilize the Plug & Connect feature (for more info please go to help.endian.com and look for the “The Plug And Connect Autoregistration Procedure” article)

2. **Restore a Backup:** choose this mode if you have any existing backup to restore.
3. **Setup Assistant:** if you want to configure your appliance manually with the configuration wizard, choose this mode and follow the steps

Endian Network Account

The Configuration Assistant will ask you for an Endian Network account, needed for your Endian Network subscription and keep your appliance always up-to-date with the latest features and security updates.

A. You already have an Endian Network account

1. When the system asks you if you have an Endian Network account choose “yes” and go to the next step.
2. Now fill in the form using your data and the activation code.

B. You do not have an Endian Network account

1. When the system asks you if you have an Endian Network account choose “no” and go to the next step.
2. Click on the “Endian Network account” link and insert the activation code on the back of this Quick Start.
3. Fill in the registration form and create your account.
4. Close the registration window and go to the next step.
5. Now fill in the form using your data and the activation code.

Your Endian appliance is now ready!

endian

Regulatory Notices

European Conformity (CE) - EU

This is a A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

Simplified EU Declaration of Conformity

This declaration is only valid for Endian products (including combinations of software, firmware and hardware) provided by Endian or Endian's authorized partners to the end-customer directly for use within the EU or countries that have implemented the EU Directives and/or spectrum regulation. Any Endian products not obtained directly from Endian or Endian's authorized partners may not comply with EU Directives and Endian makes no assurances for such products.

Deutsch Dieses Produkt entspricht der Richtlinie 2014/30/EU

English This product is in compliance with Directive 2014/53/EU

Italiano Questo prodotto è conforme alla Direttiva 2014/53/EU.

Português Este produto está em conformidade com a Diretiva 2014/53/UE

Ελληνική Το προϊόν αυτό συμμορφώνεται με την Οδηγία 2014/53/ΕΕ.

Federal Communication Commission (FCC) – USA

This device complies with Part 15 of FCC Rules. Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received; including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy, and if it is not installed and used in accordance with the instruction manual, it may cause harmful interference to radio communications. Operation of this equipment

in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Warning: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Industry Canada Equipment Standard for Digital Equipment (ICES) – Canada

CAN ICES-003 (A) / NMB-003 (A)

This digital apparatus does not exceed the Class A limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

(FR) Cet appareil numérique n'émet pas de bruits radioélectriques dépassant les limites applicables aux appareils numériques de la classe A prescrites dans le Règlement sur le brouillage radioélectrique édicté par le ministère des Communications du Canada.

The full declaration of conformity can be found here:

<https://www.endian.com/en/product-regulatory/>

EN

Cautions and Warnings

Environmental specifications

Ambient operating temperature: 0°C to 40°C

Refer to specific Product Model Data Sheet for Environmental Specifications (Operating Temperature, Storage Temperature and Humidity)

Safety

Please read the following safety instructions carefully. It is advised that you keep this manual for future references.

1. All cautions and warnings on the device should be noted.
2. All cables and adapters supplied by Endian are certified and in accord-

ance with the material safety laws and regulations of the country of sale.
Do not use any cables or adapters not supplied by Endian to prevent system malfunction or fires.

3. Make sure the power source matches the power rating of the device.
4. Position the power cord so that people cannot step on it. Do not place anything over the power cord.
5. Always completely disconnect the power before working on the system's hardware.
6. No connections should be made when the system is powered as a sudden rush of power may damage sensitive electronic components.
7. If the device is not to be used for a long time, disconnect it from the power supply to avoid damage by transient over-voltage.
8. Always disconnect this device from any AC supply before cleaning. While cleaning, use a damp cloth instead of liquid or spray detergents.
9. Make sure the device is installed near a power outlet and is easily accessible.
10. Keep this device away from humidity.
11. Place the device on a solid surface during installation to prevent falls
12. Do not cover the openings on the device to ensure optimal heat dissipation.
13. Watch out for high temperatures when the system is running.
14. Do not touch the heat sink or heat spreader when the system is running
15. Never pour any liquid into the openings. This could cause fire or electric shock.
16. As most electronic components are sensitive to static electrical charge, be sure to ground yourself to prevent static charge when installing the internal components. Use a grounding wrist strap and contain all electronic components in any static-shielded containers.
17. If any of the following situations arises, please the contact our service personnel:
 - Damaged power cord or plug
 - Liquid intrusion to the device
 - Exposure to moisture
 - Device is not working as expected or in a manner as described in this manual
 - The device is dropped or damaged
 - Any obvious signs of damage displayed on the device

Caution:

There is a danger of explosion if the battery is incorrectly replaced. Replace only with the same or equivalent type recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions and your local government's recycling or disposal directives.

Warning: Equipment intended for installation in Restricted Access Location.

DE

Vorsichtsmaßnahmen und Warnhinweise

Umgebungsspezifikationen

Umgebungstemperatur im Betrieb: 0 °C bis 40 °C

Bitte beachten Sie das spezifische Produktdatenblatt für Umweltspezifikationen (Betriebstemperatur, Lagertemperatur und Luftfeuchtigkeit).

Sicherheit

Bitte lesen Sie die folgenden Sicherheitshinweise sorgfältig durch. Es wird empfohlen, dieses Handbuch für zukünftige Referenzen aufzubewahren.

1. Alle Warn- und Sicherheitshinweise auf dem Gerät sind zu beachten.
2. Alle von Endian gelieferten Kabel und Adapter sind zertifiziert und entsprechen den Material- und Sicherheitsvorschriften des Verkaufslandes. Verwenden Sie keine Kabel oder Adapter, die nicht von Endian geliefert wurden, um Systemstörungen oder Brandgefahr zu vermeiden.
3. Stellen Sie sicher, dass die Stromquelle der Spannungsangabe des Geräts entspricht.
4. Legen Sie das Netzkabel so, dass niemand darauf treten kann. Platzieren Sie keine Gegenstände auf dem Netzkabel.
5. Trennen Sie das Gerät immer vollständig vom Stromnetz, bevor Sie an der Hardware arbeiten.
6. Es dürfen keine Verbindungen hergestellt werden, wenn das System

endian

unter Strom steht, da plötzliche Stromstöße empfindliche elektronische Komponenten beschädigen können.

7. Wenn das Gerät längere Zeit nicht benutzt wird, trennen Sie es vom Stromnetz, um Schäden durch Überspannungen zu vermeiden.
8. Trennen Sie das Gerät vor jeder Reinigung vom Stromnetz. Verwenden Sie zur Reinigung ein leicht angefeuchtetes Tuch statt Flüssig- oder Sprühereiniger.
9. Stellen Sie sicher, dass das Gerät in der Nähe einer Steckdose installiert und leicht zugänglich ist.
10. Halten Sie das Gerät von Feuchtigkeit fern.
11. Platzieren Sie das Gerät während der Installation auf einer stabilen Oberfläche, um ein Herunterfallen zu verhindern.
12. Decken Sie die Lüftungsöffnungen des Geräts nicht ab, um eine optimale Wärmeableitung sicherzustellen.
13. Achten Sie auf hohe Temperaturen, wenn das System in Betrieb ist.
14. Berühren Sie Kühlkörper oder Wärmeverteiler nicht, während das System in Betrieb ist.
15. Gießen Sie niemals Flüssigkeiten in Öffnungen. Dies könnte zu Brand oder elektrischem Schlag führen.
16. Da die meisten elektronischen Komponenten empfindlich gegenüber elektrostatischer Aufladung sind, erden Sie sich bitte vor der Installation interner Komponenten. Verwenden Sie ein Erdungsarmband und lagern Sie alle elektronischen Komponenten in antistatischen Behältern.
17. Wenden Sie sich bitte an unser Servicepersonal, wenn einer der folgenden Fälle eintritt:
 - Beschädigtes Netzkabel oder beschädigter Stecker
 - Flüssigkeit ist in das Gerät eingedrungen
 - Kontakt mit Feuchtigkeit
 - Gerät funktioniert nicht wie erwartet oder nicht wie in diesem Handbuch beschrieben
 - Gerät wurde fallen gelassen oder beschädigt
 - Sichtbare Beschädigungen am Gerät

Achtung:

Es besteht Explosionsgefahr, wenn die Batterie falsch ersetzt wird. Ersetzen Sie sie nur durch denselben oder einen gleichwertigen Typ, der vom Hersteller empfohlen wird. Entsorgen Sie gebrauchte Batterien gemäß den

Anweisungen des Herstellers und den örtlichen Vorschriften zur Wiederverwertung oder Entsorgung.

Warnung: Gerät zur Installation in Bereichen mit eingeschränktem Zugang vorgesehen.

IT

Precauzioni e avvertenze

Specifiche ambientali

Temperatura ambiente di esercizio: 0 °C – 40 °C

Fare riferimento al Data Sheet specifico del prodotto per le specifiche ambientali (temperatura di esercizio, temperatura di stoccaggio e umidità).

Sicurezza

Si prega di leggere attentamente le seguenti istruzioni di sicurezza.

Si consiglia di conservare questo manuale per future consultazioni.

1. Tutti gli avvisi e le cautele presenti sul dispositivo devono essere osservati.
2. Tutti i cavi e gli adattatori forniti da Endian sono certificati e conformi alle leggi e ai regolamenti sulla sicurezza dei materiali del Paese di vendita. Non utilizzare cavi o adattatori non forniti da Endian per evitare malfunzionamenti o incendi.
3. Assicurarsi che la fonte di alimentazione corrisponda alla tensione nominale del dispositivo.
4. Posizionare il cavo di alimentazione in modo che non possa essere calpestato. Non collocare oggetti sopra il cavo di alimentazione.
5. Scollegare sempre completamente l'alimentazione prima di intervenire sull'hardware del sistema.
6. Non effettuare connessioni mentre il sistema è alimentato, poiché improvvisi picchi di corrente possono danneggiare componenti elettronici sensibili.
7. Se il dispositivo non viene utilizzato per un lungo periodo, scollegarlo dall'alimentazione per evitare danni da sovratensioni transitorie.

8. Scollegare sempre il dispositivo dall'alimentazione prima della pulizia. Durante la pulizia, utilizzare un panno umido invece di detergenti liquidi o spray.
9. Assicurarsi che il dispositivo sia installato vicino a una presa di corrente e che sia facilmente accessibile.
10. Tenere il dispositivo lontano dall'umidità.
11. Posizionare il dispositivo su una superficie stabile durante l'installazione per evitare cadute.
12. Non coprire le aperture del dispositivo per garantire un'adeguata dissipazione del calore.
13. Prestare attenzione alle alte temperature quando il sistema è in funzione.
14. Non toccare il dissipatore o il diffusore di calore quando il sistema è in funzione.
15. Non versare mai liquidi nelle aperture. Ciò potrebbe causare incendi o scosse elettriche.
16. Poiché la maggior parte dei componenti elettronici è sensibile alle cariche elettrostatiche, assicurarsi di scaricare l'elettricità statica prima di installare componenti interni. Utilizzare un bracciale antistatico e contenere tutti i componenti elettronici in contenitori schermati antistatici.
17. Contattare il nostro personale di assistenza in caso di una delle seguenti situazioni:
 - Cavo di alimentazione o spina danneggiati
 - Ingresso di liquidi nel dispositivo
 - Esposizione all'umidità
 - Il dispositivo non funziona come previsto o come descritto in questo manuale
 - Il dispositivo è caduto o è stato danneggiato
 - Presenza di segni evidenti di danni sul dispositivo

Attenzione:

Pericolo di esplosione se la batteria è sostituita in modo errato. Sostituire solo con lo stesso tipo o equivalente raccomandato dal produttore. Smaltire le batterie usate secondo le istruzioni del produttore e le direttive locali sul riciclo o lo smaltimento.

Avvertenza: Apparecchiatura destinata all'installazione in aree ad accesso limitato.

